
# STYLE No. UNPFO1<sup>†</sup>



# **SPECIFICATIONS:**

Fittings Hole Diameter: Ø1-1/4" (32mm)

Handle Turn Angle: Quarter Turn

Inlet Connection Size & Type: 1/2" Female NPT<sup>†</sup>

Spout Reach: 23-5/8" (600mm)

Spout Swivel: Yes

Water Pressure Minimum: 20psi (1.4 Bar) Water Pressure Maximum: 80psi (5.5 Bar) Water Pressure Recommended: 45 psi (3 Bar)

<sup>†</sup> UK Style No. **UN01PF** is supplied with a **BSP** adapter, assembly required.

# IMPORTANT:

- > To ensure this product is installed properly, you must read and follow these guidelines.
- > The owner/user of this product must keep this information for future reference.
- > This product must be installed by a professional licensed contractor.
- Be sure your installation conforms to all federal, state, and local codes.
- In the State of Massachusetts, all installations must comply with the rules and regulations set forth within 248 CMR.
- This product must be on-site prior to rough-in. This allows the installer to visualize the installation and verify dimensions.
- Inspect the product to ensure you have all the parts required for proper installation.
- Use only a strap wrench or protected/smooth-jaw wrench on any finished surface.

# Installation Guidelines

- > DO NOT use putty. Putty contains oil and can cause permanent discoloration on certain materials such as marble, granite and any porous surface.
- Refer to the specification and assembly drawings attached. Product is sold partially assembled but shown fully disassembled for illustrative and service purposes only.
- > Check incoming water pressure.

#### **ROUGH-IN:**

 Determine the ideal location based on the clients preference. Take into account the SPOUT dimensions shown in Figure - 01 and (if available) the height of the pot(s) the client will use.




FIGURE - 01

- Install adequate blocking to properly support the inlet supply and MOUNTING HARDWARE.
- 3. Finish the rough-in by installing a well supported 1/2" male NPT connection. The inlet supply must project 1/2" to 5/8" from the finished wall. See Figure 02.

**REQUIRED:** The 1/2" male NPT connection <u>must</u> be secure, plumb and level. Failure to properly secure the pipes will cause the POT FILLER to sit crooked.




FIGURE - 02

4. Make sure a 1-1/4" (32mm) hole is cut in the finished wall to allow for proper mounting.

These guidelines have been prepared for the professional contractor to aid in the installation of: UNIVERSAL MODERN WALL MOUNTED ARTICULATED POT FILLER WITH METAL LEVER HANDLE (STYLE No. UNPF01, UN01PF UK)

All dimensions are based on original specification and are subject to change and variation. Please consult your Design Associate for current specifications.

WATERWORKS

# Installation Guidelines

# **INSTALLATION:**

- 5. Install the MOUNTING PLATE on the finished wall in the correct orientation, as shown in Figure 03.
- Use the appropriate screws and anchors based on the mounting surface material. <u>Screws and anchors are not supplied.</u>




FIGURE - 03

- 6. Loosen the 4 SET SCREWS on the MOUNTING PLATE.
- Slide the ESCUTCHEON up the VALVE BODY then thread the VALVE BODY onto the 1/2" male NPT connection. See Figure - 04. Make sure to securely tighten the POT FILLER.




FIGURE - 04

- 8. Securely tighten the SET SCREWS onto the VALVE BODY, then slide the ESCUTCHEON against the finish wall.
- > The SET SCREWS will prevent the POT FILLER from rotating.
- If desired, a bead of caulk or a clear silicone may be applied where the escutcheons contact the finished wall. DO NOT use putty.\*
- 10. Remove the AERATOR from the SPOUT using the TOOL provided then open the inlet supply water and carefully turn the HANDLE to flush out any debris in the supply lines.
- 11. Inspect all connections for leaks then re-install the AERATOR.

# **SERVICING THE SHUT-OFF CARTRIDGE:**

12. To access the CARTRIDGE, unthread the GLAND COVER and remove the HANDLE. See Figure - 05.




FIGURE - 05

- If further assistance is required, please contact
  Product Support at 1-800-927-2120 Ext 2 Monday
  through Friday, 8am 6pm EST.
- Putty contains oil and can cause permanent discoloration on certain materials such as marble, granite and any porous surface.

These guidelines have been prepared for the professional contractor to aid in the installation of: <a href="https://www.ncbern.wall-mounted-articulated-pot-filler-with-metal-lever-handle">www.ncbern.wall-mounted-articulated-pot-filler-with-metal-lever-handle</a> (STVI F No. LINPER) LINDIPE LIK)

(STYLE No. UNPFO1, UN01PF UK)

All dimensions are based on original specification and are subject to change and variation. Please consult your Design Associate for current specifications.

WATERWORKS